

# Assignment

---

## Chapter 12 | 12.4 Domestic Electric Circuits

### Question

1. Name two safety measures commonly used in electric circuits and appliances.
2. What precaution should be taken to avoid the overloading of domestic electric circuits?

**Email to:** [techtutor.megh@gmail.com](mailto:techtutor.megh@gmail.com)